

A

ir Rifle 612



Slavia

Technical data:

Length of air rifle	830 mm
Height of air rifle	148 mm
Width of air rifle	25 mm
Weight of air rifle	1.20 kg
Calibre	4.5 mm
Muzzle velocity	approx. 74 m/sec.
Smooth barrel bore.	

Ammunition: Shot No. 11 — darts cal. 4.5

Slavia air rifle Model 612 is used for target shooting at a range of 8 m and is designed for children up to the age of 10 years under the supervision of adults.

Cocking and loading of air rifle:

It is necessary before shooting to remove thoroughly the preserving layer from the barrel and the air chamber in front of the piston by cocking and releasing the unloaded rifle several times. The easiest way of cocking and loading the air rifle is to put the stock under the right arm and by holding the barrel with the left hand by the muzzle to break-open the rifle. Inserts a shot No. 11 or a dart (cal. 4.5) into the rear part of the barrel and by returning it to the original position the rifle is ready for shooting. For shooting use shot No. 11 or cal. 4.5 dart exclusively.

Removing defects most likely to occur:

In the first place we wish to stress the fact that each air rifle is thoroughly checked and tested before dispatch to ensure its per-

fect function. If the penetrating force of the air rifle should be insufficient it is a sign that the leather packing is dry (insufficiently pliable) and, therefore, it is necessary to apply a few drops of oil through the hole in the receiver after break-opening the barrel. By releasing the trigger in an unloaded state, i. e. without shots the leather packing is extensively rammed and the movement of the piston braked. In such a case it is necessary to dismantle the rifle and according to the degree of damage the leather packing must be expertly trimmed or exchanged.

Never leave the air rifle cocked if it is not in use, because the piston spring becomes fatigued and loses its strength.

Spare parts:

Item	Designation
9	Rear sight screw
16	Front sight
29	Piston assy (31 piston shell, 33 large packing insert, 34 piston packing, 35 piston packing insert, 36 small packing insert, 37 piston insert)
43	Piston spring
44	Barrel packing
52	Cocking lever pin
53	Cocking lever nut pin
56	Trigger mechanism assy (57 -trigger, 58 trigger claw)
60	Trigger spring
72	Trigger pin
73	Trigger guard
75	Connecting pin
76	Connecting pin nut

Made in Czechoslovakia

REGENT SPORTS COMPANY

131 Varick Street
New York 11, N. Y.